



www.chefproindia.com

Powered by *Chef Pro*



NON STICK COOKWARE

Powered by *Chef Pro*

Use & Care



North American Mercantile India Pvt. Ltd.
Customer Care No.: 022-6136 8888
Email: customercare@chefproindia.com



Thank you for your purchase of new Eris™ cookware for Modern Kitchen. Rinse your new cookware with hot water and dry with a towel. Prior to use apply vegetable oil to the cooking surface and place on low heat. After a few minutes, the cookware is ready to cook.

If necessary, let the cookware cool and wash with detergent and warm water and soft cloth or soft sponge. Do not use any abrasive sponge or chemicals.

Directions for use

Eris™ cookware for Modern Kitchen is suitable for all cooktops, gas, electric and induction cooktops. Eris™ cookware is manufactured with precision to distribute heat evenly and efficiently. **Only low to medium burner heat is recommended.**

Caution:

1. Do not use on high heat
2. Use only on the cook tops where the heat can be regulated.
Use only on low to medium heat.
3. Do not preheat for more than 3 minutes.
4. Avoid overheating the cookware and never let cookware boil dry on a cook top as it can cause severe damage and can be a safety hazard.
5. Do not use metal tools or sharp objects.
6. Do not put hot cookware in cold water.

Easy Cleaning:

1. In order to maintain the appearance of your cookware, we recommend:
2. Immediately after cooking, remove cookware from heat and let it cool on a trivet or heat resistant surface.
3. Wash with warm water, liquid soap and soft cloth or sponge. Do not use any abrasive sponge or any chemicals.

Eris™ is a trademark of North American Mercantile India Pvt. Ltd.
For household use only

आधुनिक रसोई के लिये नये Eris™ Cookware की अपनी खरीदी के लिए धन्यवाद। अपने नए Eris™ Cookware उपयोग में लाने से पहले गरम पानी से धो लें और सुखे कपड़े से साफ करें। इस्तेमाल करने से पहले Cookware में वनस्पती तेल डालें और धीमी आंच पर रखें। कुछ ही मिनट बाद Cookware इस्तेमाल के लिये तैयार है।

यदि आवश्यक हो, Cookware को थंडा होने दें, साबुन और गरम पानी से धोकर मुलायम कपड़े या नरम स्पंज से साफ करें। किसी भी घर्षण स्पंज या किसी रसायन का इस्तेमाल ना करें।

उपयोग के लिये निर्देश

Eris™ Cookware आप Electric चुले के साथ ग्यास चुले पर भी इस्तेमाल कर सकते हैं।

Eris™ Cookware समान रूप से और कुशलता से गर्मी वितरित करने के लिये परीशुद्धता से बनाया गया है। केवल धीमी से मध्यम आंच पर ही इस्तेमाल करें।

सावधानी :

1. उच्च तापमान पे इस्तेमाल ना करें।
2. आंच नियंत्रित की जा सकती है ऐसे चुले का ही इस्तेमाल करें। धीमी से मध्यम आंच का ही इस्तेमाल करें।
3. इस्तेमाल से पहले 3 मिनट से ज्यादा गरम न करें।
4. Cookware ज्यादा गरम ना करें, तथा खाली Cookware ग्यास चुले पर या Electric चुले पे इस्तेमाल ना करें, इससे Cookware को भारी नुकसान हो सकता है और सुरक्षा हेतु भी ये हानीकारक है।
5. मेटल या अन्य तेज धार वाले वस्तु का प्रयोग ना करें।
6. गरम बरतन थंडे पानी में ना रखें।

सफाई करने का आसान तरीका :

1. आप के Cookware कि सुरक्षा के लिये हम सलाह देते है कि :
2. खाना बनाने के तुरंत बाद, Cookware आंच से हटाये और गरम प्रतियोधी सतह पर रख दें।
3. Cookware केवल गरम पानी, तरल साबुन और मुलायम कपड़े से या नरम स्पंज से साफ करें। किसी भी घर्षण स्पंज या किसी रसायन का इस्तेमाल ना करें।

Eris™ नॉर्थ अमेरिकन मर्कन्टाईल (इंडिया) प्रा. लि. का ट्रेडमार्क है।

केवल घरगुती इस्तेमाल के लिये।